



**Tri-Band GSM
X-Two Watch Phone
USER MANUAL**

© PHENOM COMMUNICATIONS INC. 2009



Contents

1	FOREWORD.....	4
2	SAFETY IN USE AND PRECAUTIONS	5
2.1	PLEASE KEEP TO THE FOLLOWING PRECAUTIONS WHILE USING THE PHONE	5
2.2	PLEASE KEEP TO THE FOLLOWING PRECAUTIONS WHILE USING THE BATTERY	6
2.3	PLEASE KEEP TO THE FOLLOWING PRECAUTIONS WHILE USING THE CHARGER	6
3	NOTICE BEFORE USE	8
3.1	SIM CARD	8
3.2	SIM CARD INSTALLATION AND REMOVAL	8
3.3	BATTERY.....	8
3.4	INSTALLATION AND REMOVAL OF BATTERY	9
3.5	CHARGING THE BATTERY	9
3.6	INSTALLATION OF T-FLASH CARD	10
3.7	USB CONNECTING WIRE.....	10
3.8	SAFETY CODE	10
4	GENERAL TO THE PHONE.....	12
4.1	INTRODUCTION TO KEYS	12
4.2	INTRODUCTION SYMBOLS.....	12
5	PHONE BOOK	13
5.1	QUICK SEARCH	13
5.2	SEARCH ENTRY	13
5.3	ADD NEW ENTRY	14
5.4	COPY ALL.....	14
5.5	DELETE.....	14
5.6	CALLER GROUP.....	15
5.7	EXTRA NUMBER.....	15
5.8	SETTINGS	15
5.9	CALLER PICTURE	15
5.10	CALLER RING TONE.....	16
6	MESSAGES.....	17
6.1	SMS	17
6.2	MMS	19
6.3	CHAT	21
6.4	VOICE MAIL SERVER	21
6.5	BROADCAST MESSAGE	22
7	CALL CENTER.....	23
7.1	CALL HISTORY.....	23
7.1.1	<i>Missed Calls</i>	23
7.1.2	<i>Dialed Calls</i>	23
7.1.3	<i>Received Calls</i>	23
7.1.4	<i>Delete Call Log</i>	24
7.1.5	<i>Call Time</i>	24
7.1.6	<i>Call Cost</i>	24
7.1.7	<i>SMS Counter</i>	24
7.1.8	<i>GPRS Counter</i>	25
7.2	GENERAL CALL SETTING	25
7.2.1	<i>Call setting</i>	25
7.2.2	<i>Auto Redial</i>	26
7.2.3	<i>Speed Dial</i>	26
7.2.4	<i>IP Number</i>	26
7.2.5	<i>More</i>	26
8	SETTINGS	28
8.1	DUAL SIM SETTINGS	28

8.2	PHONE SETUP	28
8.3	NETWORK SETUP.....	29
8.4	SECURITY SETUP	29
8.5	SHORTCUTS	30
8.6	PEN CALIBRATION	30
8.7	RESTORE FACTORY SETTINGS	30
9	MULTIMEDIA	32
9.1	CAMERA.....	32
9.2	IMAGE VIEWER.....	33
9.3	VIDEO RECORDER.....	33
9.4	VIDEO PLAYER	33
9.5	AUDIO PLAYER	34
9.6	SOUND RECORDER.....	35
10	FILE MANAGER	36
11	FUN & GAMES.....	38
11.1	GAMES	38
12	USER PROFILES	40
13	ORGANIZER.....	41
13.1	CALENDAR	41
13.2	TO DO LIST	41
13.3	ALARM.....	42
13.4	WORLD CLOCK	42
13.5	CALCULATOR	42
13.6	CURRENCY CONVERTER.....	43
13.7	STOPWATCH	43
13.8	E-BOOK READER	44
13.9	BLUETOOTH	45
14	SERVICE	48
14.1	WAP.....	48
14.2	DATA ACCOUNT	49
15	TRANSMISSION.....	50
16	FITTINGS.....	51

1 FOREWORD

Thank you for your choice of the product of this company! For using your mobile phone kinder, we suggest you to read this guide carefully, so that you can use various function explained in the product documentation.

This type of phone is elaborately designed for you, which will be a kind assistant for your work and life with the powerful and practical functions. The phone not only receives the features of traditional phones including handy, practicality, but also absorbs the currently new and practical advanced technologies, including GPRS high speed on line and the switching of net signals between single frequency and dual frequency. The high-active smart characters input system enables you to enjoy the humanized interest of sophisticated science and technology.

The product is in accordance with the communication standards of the People's Republic of China as well as European Standards, and it is applicable to GSM network after approval. The product is of GPRS function, and GSM network is a kind of global cellular communication system conforming to international standards. Your phone can load various international networks and enables you to dial and receive international calls. However, it is necessary for you to purchase the required services to use the advanced functions offered by internet.

Please contract the company or agent and distributor for consultation if you are unclear as to the explanation in words. The company will not be responsible for any inconvenience or damage resulting form the use of this manual.

There is no further notice for alternation of the contents of the manual as a result of new versions.



Hint *In view of the network configuration and the services provided, some of the functions might not be available, please enquire from the distributor or network operator.*

2 SAFETY IN USE AND PRECAUTIONS

Please read the following simple rules and keep to them to prevent risks and violation.

2.1 Please keep to the following precautions while using the phone

- Please read the manual carefully before using.
- Please keep your phone off while on the flight. If the alarm and memo are of auto-on function in off state, please check and cancel such settings before embarkation.
- Please keep off heat source and high-voltage environment when using the phone, such as electrical appliance and electric cooking equipment. Please use at normal temperature, otherwise, your phone shall be damaged in the environment with a temperature over 55□ or below 10□.
- Fire safety. Please switch off your phone near combustible materials, including chemical plants, service stations and fuel depots and the like.
- No hand holding of the phone while driving. Don't put your phone on the air bag or the area where the air bag shall reach after expanding, to avoid the grievous injury to the owner due to the strong outside force on the phone caused by the expanding of the air bag.
- Only the standard battery, charger and fittings approved by this company shall be used. The company shall not be responsible for any aftereffect resulting from the use of fittings of third party.
- No of disassembling the phone without authorization.
- The phone shall affect other electronic equipment when it is close to it the electronic equipment. Please keep your phone away from the electronic equipment, including TV, radio and PC and the like. It is forbidden to place the phone where close to credits or magnetic field.
- Please switch off your phone near hospital or convalescent home, or else, it may influence the medical electronic equipment, such as hearing aids and pacemaker and the like.
- No mechanical vibration or shaking of the phone. It is forbidden to knock the screen with sharp tool.
- The shell coating may be damaged for using of phone case or plastic phone case.
- Don't use solute, including benzene, diluents or alcohol and the like, to clean the phone shell, and keep the phone off corrosive chemicals and cleanser. You can only use clean soft cloth to clean the phone gently.
- It is forbidden to expose the phone in the sunlight or hazy and dusty places.
- Keep it dry and don't use in the environment with high humidity, such as the bathroom. The set is not non-waterproof, so keep it off the rain and damp.
- Please use the fittings carefully, such as earphone and the like. It is forbidden to touch the aerial if not necessary. Only the original air wire shall be used, and it may lead to the damage to the phone in case of using unauthorized aerial.
- When you pull the charger connector out of the phone, firmly grasp the connector to pull outwards, and it is strictly forbidden to pull the power line.
- Don't merely rely on the phone for urgent means of communication, such as medial aid.
- Please place the phone out of the touch of children to avoid danger.


2.2 Please keep to the following precautions while using the battery

- Please read the manual and surface marks on the battery carefully before using.
- Make sure that the phone has been switched off before taking the battery out,
- Please charge the battery in cool and airy house. Or else, over-high environmental temperature shall cause the warming, smoking, burning or distortion and even burst of the battery while charging.
- As there are special protective circuit and devices inside the battery, it is forbidden to apart the battery without authorization, or else, it shall lead to the damage to liquid crystal panel and leakage of liquid crystal fluid. Splashing the liquid into eye may lead to the danger of blindness. If so, please flush the eye with clean water (no kneading the eye), and see a doctor immediately.
- It is forbidden to press the battery, to mechanical vibrate or shake the battery and short the battery, which shall damage the battery or the component elements connected to it. Short circuit shall directly connect the positive pole of the battery with the negative pole by some metallic products, including coin, pen and clip and the like, and thus it is forbidden to put the battery together with metallic products.
- Please the metal contacts and battery clean.
- Using of damaged or used battery is forbidden.
- Please replace the battery in case of not satisfying the performance requirements. The battery can be charged hundreds of times until it is required to be changed. Battery is a kind of consumables, the electric quantity shall decrease slowly despite it is available to be charged and discharged for hundreds of times. If you find that the hours of use (speaking time and idle time) drops off, please change for a new one immediately.
- It is forbidden to expose the battery in the sunlight or hazy and dusty places. Don't use in the environment with high humidity, such as the bathroom. The set is not non-waterproof, so keep it off the rain and damp.
- Don't put the battery in overheated or super-cooled places.
- It is forbidden to throw the battery in fire to avoid burst.
- It is forbidden to put the battery in water, which shall result in warming, smoking, burning, distortion or even burst of the battery due to inner short circuit.
- Please dispose the battery according to relevant regulations (such as recycle), and it is not permitted to treat the battery as domestic waste, in order to avoid the burst and pollution.
- Only the special charger can be use to charge the battery, and the trickle charge time shall not exceed 24 hours.
- Please place the battery out of the touch of children to avoid danger.

2.3 Please keep to the following precautions while using the charger

- Please read the manual and surface marks on the charger carefully before using.
- Don't disassemble or refit the charger, or use the charge when the power line is damaged, or else, it may lead to electric shock, burning and the damage to charger.


- It is forbidden to touch the charger with wet hand; cut off the power supply immediately if the charger touches water or other liquids.
- It is forbidden to short the charger, to mechanical vibrate or shake the charger, to expose the charger in the sunlight, and to use in the environment with high humidity, such as bathroom. The set is not non-waterproof, so keep it off the rain and damp.
- Don't use the charger near electronic equipment, including TV, radio and the like.
- When you pull out the plug, firmly grasp the charger, and the wire shall be damaged for pulling the power line.
- Please place the battery out of the touch of children to avoid danger. Protect the battery against damp, or else, it shall result in overheat, smoking and corrosion of the battery.

 **Attention** *If the phone is equipped with the functions of taking photos, videotaping and sound recording, please make sure to observe relative laws and regulations for using such functions. Taking photos from or recording for others or any personal characteristics without authorization as well as duplicating and delivering shall be regarded as the invasion of privacy. The photos, videotapes and sound records achieved through inappropriate use of photo taking, videotaping and sound recording functions shall violate the rights of copyright owners. The use must be fully responsible for this. This company will not be responsible for the damages resulting from inappropriate use of the phone.*

3 NOTICE BEFORE USE

3.1 SIM card


- You will get a SIM (Subscriber Identity Module) card provided by the network service provider when registering the mobile phone number. If the SIM card has the same size as a credit card, take the relatively small part out and get rid of the peripheral part.
- The SIM card will enable you to use all functions of the phone. All the information related to the establishment of network connection is recorded in the chip of SIM Card, along with your personal information, including PIN code (personal identification number), short messages and other extra system services.
- Please carefully use your SIM card, do not distort or press it, avoid touching the metallic contact surface as far as possible, put it where away from electricity and magnetism, keep it off dust and water. Your phone shall not work normally once the SIM card is damaged.

 **Attention** *Make sure that the phone has been switched off before taking out the SIM card, and then take out the battery.*

3.2 SIM card installation and removal

Installation of SIM card:

- ✧ Turn the back side of the phone up, push the back cover outwards to remove the back cover of the phone.
- ✧ Make sure that the gold-colored contacts on the card are face down, and then insert it to the seat of SIM card. Make sure that the bevel angle of SIM card is aligned with the bevel angle of the card seat.
- ✧ Push SIM card to the end.
- ✧ Push the battery cover until you hear the noise of “crack”, then put on the battery cover again, and make sure that there is no gap between the phone and cover.

 **Note:** *please insert anyone SIM socket if you have only one SIM card, and the device can work in normal.*

Removal of SIM card

- ✧ It is only necessary to press the peripheral part of SIM card and slide out slowly for removal. Other operations are the same as the installation of SIM card.

3.3 Battery

- Battery used for this phone is the repeatable secondary battery. The new battery will achieve its optimum performance after two or three full charge/discharge cycles. It is suggested that charge the battery until the electric quantity of the battery is insufficient and the phone automatically powers off.

- In the process of charging, slight warming of the battery is a normal phenomenon; your phone will active the protection to control the temperature variation when the temperature of the battery is rising.
- Use the authorized battery and fittings only, or else, the phone shall be damaged.
- Make sure to switch off the phone before taking off the battery, or else, it is possible to lose the data stored in the phone and influence the service life of the phone.
- Cut off the connection with the phone and extract the connector plug of the charger from the outlet when the charger is not in use. Don't connect the full charged battery to the charger for a long time, because overcharge shall shorten the service life of the battery. If the full charged battery is laid up, it will discharge after a period of time.
- Don't use the battery for other purposes. Don't use any damaged charger or battery. Don't short the battery. When some metal products (such as coins, pin and pens and the like) connect the positive pole directly with negative pole (i.e. the small metal strip on battery) by accident, short circuit shall happen.
- If place the battery in overheated or overcooled places, it shall reduce the capacity, service life and charging capacity of the battery.
- Please don't throw the battery into fire to avoid burst. Damaged battery may lead to burst. Please dispose the battery according to local regulations. Please call back the battery if available. It is not permitted to treat the battery as domestic waste.

3.4 Installation and removal of battery

Installation of battery

- ◇ Make the gold-colored contacts on the battery are face down to the phone.
- ◇ Insert the plug-handle on co-boundary of the battery to the plug hole of the battery seat.
- ◇ Press the battery until the noise of "crack" appears, clipping the battery fully in the battery seat.
- ◇ Put on the back cover of the phone.

Removal of battery

- ◇ Make sure that the phone has been switched off, and the charger or any other facility has been taken off from the phone.
- ◇ Turn the back side of the phone up, press the release button on back cover to take out the back cover of the phone.
- ◇ Find out the release button at the bottom of the battery, turn up and take out the battery.

3.5 Charging the battery

- ◇ Make sure that the battery has been installed in the phone.
- ◇ Find out the plug hole of the phone charger. Connect the battery to the charger and connect the charger to power supply.
- ◇ When charging is finished, please pull out the charger from the outlet firstly, and then press the release buttons at both sides of the charger to take the charger out of the phone.

- ✧ After inserting the charging plug, if the battery strength symbol stripe rolls on the screen, it shows that the charging has begun; when the stripe fills up the whole symbol and stops rolling, it shows that charging has finished; press the buttons at both sides of the charger to pull out the plug.

- !Attention** *1. When electric quantity is insufficient, warning message shall display on the screen, and meanwhile, the electric quantity of the battery shows to be empty. The phone shall automatically powers off when the electric quantity is too low. Don't keep the battery in the state of insufficient electric quantity for a long time, or else, the quality and service life of the battery shall be damaged.*
- 2. Make sure to use the authorized charger to ensure normal working of the phone.*

3.6 Installation of T-flash card

- ✧ Firstly, find out the position of T-flash card seat.
- ✧ Just insert the T-flash card in the T-flash card seat. Please make sure that the gold-colored contacts on T-flash card are face down when installing.

- !Attention** *1. Don't insert any other thing in the spigot of T-flash card expect the card; please take care of insertion and removal of the card to avoid scratch bend the T-flash card and metal surface.*
- 2. Don't put up labels and the like on T-flash card, because subtle change of the thickness of T-flash card may lead to the difficulty in insertion and removal or even the lost of data or information.*

3.7 USB connecting wire

- ✧ Connect the USB connector to the USB interface of the computer (desktop computer or notebook PC).
- ✧ Connect the other end of USB connector to the charging interface of the phone.

- !Attention** *The two functions of download and charging shall be available through USB connection.*

3.8 Safety code

- ✧ PIN number

This is the personal identification number of your SIM card, which is often provided by operating company together with SIM card.

If the PIN number is entered three times in a row, your phone will automatically lock up the SIM card and it is necessary to enter PUK number to unlock. Please contact the network operator for details of unlocking.

- ✧ PIN2 number

PIN2 number is provided with some SIM cards. Providing you this code by network operator is required to be entered when using some functions (such as charge unit, using fixed dialing).

If the PIN2 number is entered three times in a row, it is also necessary to enter PUK2 number to unlock. Please contact the network operator for details of unlocking.

✧ PUK number

PUK number, namely Personal Unlock Key, is required for changing the locked PIN number. PUK number is provided together with SIM card. Otherwise, please contact your service provider to ask for the code. Please contact your service provider either in case of losing the code.

✧ PUK2 number

PUK2 number, namely Personal Unlock Key, is required for changing the locked PIN2 number. Please contact your service provider to get the PUN2 number if it is not provided together with SIM card.

4 GENERAL TO THE PHONE

4.1 Introduction to keys

The main typical functions of function keys are listed in the table below.

Name	Explanation
End Key	Dial or answer phone call Browse call records by pressing this key under standby mode
dial key	Dial or answer phone call Browse call records by pressing this key under standby mode
function confirmation key	Perform the words at screen bottom line .
Volume control key	Under standby mode ,press up key to increase volume ,and down key to minus volume Under talking status , press up key to increase volume ,and down key to minus volume, long time press up key to record voice and down key to end recording . Under music playing status , short time press up key to increase volume, short time press down key to minus volume, long time pressing up and down key to adjust key press volume

4.2 Introduction symbols

Difficult symbols shall display on the screen according to the different function used and different options selected.

- ✧ If the battery intensity is full, it indicates that the battery has much power;
- ✧ The more the network signals intensity bars are, the stronger the signals are;
- ✧ The appearance of GPRS symbols on the idle screen shows the conduction of GPRS business which is provided by network operator.
- ✧ Call symbol shows the existence of missed call;
- ✧ When the inbox has the unread SMS, this icon will appear on the idle screen; the full symbol will appear when the SMS capacity of inbox is full;
- ✧ The setting symbol will appear on the idle screen when the environmental setting are set as general, meeting, outdoor, indoor and the like;
- ✧ Alarm symbol shows the start of alarm setting;

5 PHONE BOOK

The phone book of this phone has two kinds of memory banks which are separately SIM card and the phone. It is possible to memorize the information of visiting card including the name, phone number, home number, company name, Email address, office number, fax number, birthday, associate picture, associate video, associate sound and caller group. The phone book entry memorized in SIM card can only store the name and phone number.

- In idle state, enter a series of numbers and press the Function confirmation key to store. If the user has selected the storage location, the editing interface shall appear.
- In idle state, press the end key to directly enter and view the phone book.
- ◇ View all of the entries in phone book. The small symbol at the left of the phone book list shows that the entry is recorded in SIM card or phone, and the right is the name information of the entry.

5.1 Quick search

This function enables your searching the required phone number in phone book.

5.2 Search entry

It enables the user to search the entry in line with the searching term in phone book.

After entering the name, select search to enter entry list, then the selector bar will be on the searched entry; press the call key after selecting an entry; if the selected entry has only one phone number, it will be possible to dial immediately, however, if the entry includes several phone numbers, it will be necessary to enter the phone number list to select.

In the interface of entry list, press the function confirmation key to carry out the following operations.

- ◇ Add New Entry: Add a new item of entry in phone book, and it is possible to select to add to the phone or to SIM card.
- ◇ SIM1 IP dial: When IP dial number has been set and opened, the selected number shall be dialed out by SIM1 with the IP number added before if selected.
- ◇ SIM2 IP dial: When IP dial number has been set and opened, the selected number shall be dialed out by SIM2 with the IP number added before if selected.
- ◇ Send SMS: Send SMS to the selected record, enter to SMS editor.
- ◇ Send MMS: Send MMS to the selected record, enter to MMS editor.
- ◇ View: view the details of the entry.
- ◇ Edit: this function shall re-edit the items included in the entry of the phone book.
- ◇ Delete: delete this entry.
- ◇ Copy: copy the entry form the current storage site to another storage site. That is to say, copy the phone numbers in the phone book of the phone to SIM card, or copy the phone numbers in the phone book of SIM card to the phone, or copy the phone numbers in the SIM card to other SIM card.

- ✧ Move: move from the current storage site to another storage site. That is to say, move the phone numbers in the phone book of the phone to SIM card, or move the phone numbers in the phone book of SIM card to the phone, or move the phone numbers in the SIM card to other SIM card. The record in primary storage will not exist.
- ✧ Duplicate: duplicate a copy of entries from the current storage site.
- ✧ Send vCard: send out the visiting card through SMS and MMS, or store the visiting card in file manager.
- ✧ Print: Connect the Bluetooth printer by Bluetooth, print the selected phonebook record.

5.3 Add new entry

Add a new item of entry in phone book, and it is possible to select to add to the phone or to SIM card.

- ✧ To SIM1: enter the editing interface of SIM card to input the name and phone number, the record will be saved in SIM1.
- ✧ To SIM2: enter the editing interface of SIM card to input the name and phone number, the record will be saved in SIM2.
- ✧ To the phone: enter the editing number of the phone to select to input the name, several numbers, company name, email address and birthday and so on.

5.4 Copy all

It is possible for you to select to copy all of the phone numbers in SIM card to phone; or select to carry out the reverse copy operation.

- ✧ From SIM1 to phone: copy all of the phone numbers in phone book recorded in SIM1 card to the phone.
- ✧ From phone to SIM1: copy all of the phone numbers in the phone to SIM1 card, which only copies the name and phone number.
- ✧ From SIM2 to phone: copy all of the phone numbers in phone book recorded in SIM2 card to the phone.
- ✧ From phone to SIM2: copy all of the phone numbers in the phone to SIM2 card, which only copies the name and phone number.
- ✧ From SIM1 to SIM2: copy all of the phone numbers in phone book recorded in SIM1 card to the SIM2 card.
- ✧ From SIM2 to SIM1: copy all of the phone numbers in phone book recorded in SIM2 card to the SIM1 card.

5.5 Delete

You can select to delete all entries in SIM card and the entries in your phone, and you can also select to delete one by one.

If you have selected to delete the entry in SIM card or your phone, it is necessary to input correct number to operate when you have set the PIN number or phone code.

5.6 Caller group

The phone supports the caller group function, and therefore, you can select the group and view and edit the details of the group in the interface of caller group list, including the name of caller group, the ring tone of caller group, associate picture of the group and members of the group.

- ✧ Name of the group: you can edit it through the function confirmation key.
- ✧ Ring tone of the group: you can select the ring tone through the navigation key.
- ✧ Associate picture of the group: you can select through the navigation key and view through the function confirmation key.
- ✧ Group members: you can add or delete the member.

5.7 Extra number

It is possible for you to set the owner number, service dial number and SOS number through this menu.

- ✧ Owner number: it is possible to edit and set owner number for SIM1 or SIM2, and two groups of owner numbers at most for each SIM card.
- ✧ Service dial number: it is possible to view and input service dial number for SIM1 or SIM2 by the support of SIM card.
- ✧ SOS number: it is possible to input SOS number and store it in the phone, which shall be called out without the insertion of SIM card or unusable of the network.

5.8 Settings

In this menu, you can select the items of memory status, preferred storage, fields, display of number list and my vCard and the like.

- ✧ Memory status: you can enquire the memory status of the phone book of the phone and SIM card and the space occupied.
- ✧ Preferred storage: set the default preferred storage for phone numbers, furthermore, it shall be selected when storing.
- ✧ Fields: you can set whether to display home number, company name, Email address, office number, fax number, birthday, associate picture, associate video, associate sound and caller group.
- ✧ My vCard: you can edit your card and send it to others.
- ✧ vCard version: you can select the version of your card.

5.9 Caller picture

You can set the associate picture for the contacts stored in your phone.

It is necessary for you to select the required picture from file manager to set the associate picture; select the function confirmation key to enter the preview interface of the associate picture and then select to set the associate picture to new entry, original entry or caller group after clicking OK.

When the phone linkman calls in or you call out the number of the linkman, the phone will automatically match the corresponding associate picture.

5.10 Caller ring tone

In this menu, you can set different rings for different groups and persons separately according to your personal taste.

There are large amounts of in-built rings for your selection. You can also select the blank to replace the ring tone. Select the proper ring tone and set it to new entry, original entry or caller group after clicking OK.

6 Messages

This function allows you to send, receive, create and save various messages. It needs the support from the network. Please contact the network operator for details.

6.1 SMS

- The screen will show the signal as receiving the message.
- The phone will give a ring if the receiver has received your message. (on the condition that the tone and status report are ON).
- If the memory of messages is full, the phone will not receive any message any more. Once there is free memory after deleting the old messages, the un-received messages will be received.

The message mainly includes Inbox, Outbox, Write Message, Template and Message Settings.

• **Inbox:** to view all SMS received by SIM1 and SIM2 apart. Select Inbox to enter the list interface, select message with Volume control key and press function confirmation key to read the message; meanwhile you can also press Options to do the following operations:

- ✧ Reply: to reply the current sender and enter the editing interface.
- ✧ Delete: to delete the current message.
- ✧ Edit: to enter the edit box.
- ✧ Forward: you can send this message to one person or select "Multiple Sending" to send this message to more than one person or send this message to all members of a group by selecting Group Sending.
- ✧ Copy to phone/copy to SIM card: this option will be displayed as "save to phone" when the message was saved in SIM card and vice versa. This option allows you to copy the messages to phone or to SIM card.
- ✧ Move to phone/move to SIM card: this option will be displayed as "move to phone" when the message was saved in SIM card and vice versa. This option allows you to move the messages to phone or to SIM card and the messages will not be saved in the original carrier.
- ✧ Chat: this function allows you to carry out the relevant settings and chat. Please refer to the chatting module for details.
- ✧ Delete all: to delete all the messages in Inbox.
- ✧ Copy all: you can copy all the messages from SIM card to phone and vice versa.
- ✧ Move all: you can move all the messages from SIM card to phone and vice versa and the messages will not be saved in the original carrier.
- ✧ Use number: to extract the numbers such as the numbers contained in messages, number of sender and the like and carry out the operations of Call, Save, Send Message and so on to the numbers.
- ✧ Use URL: to extract the website links contained in messages and access them. You can also add this address to bookmark of web service.
- ✧ Save objects: if the current message contains pictures, animations or rings, you can save the objects in file manager with this option. This option will not be showed if there is no object in the message.

- Outbox: read or deal with the messages in it. Select Outbox to enter the list interface, select message with Volume control key and press function confirmation key to read the message; meanwhile you can also press Options to do the following operations:
 - ✧ Send from SIM1/ Send from SIM2: you can send the selected message by SIM1 or SIM2 to one person, more than one person or members of group.
 - ✧ Edit: enter the edit box and the content of message will be brought to the edit box.
 - ✧ Delete: to delete the current message.
 - ✧ Copy to phone/copy to SIM card: this option will be displayed as “save to phone” when the message was saved in SIM card and vice versa. This option allows you to copy the messages to phone or to SIM card.
 - ✧ Move to phone/move to SIM card: this option will be displayed as “move to phone” when the message was saved in SIM card and vice versa. This option allows you to move the messages to phone or to SIM card and the messages will not be saved in the original carrier.
 - ✧ Delete all: to delete all the messages in Outbox.
 - ✧ Copy all: you can copy all the messages from SIM card to phone and vice versa.
 - ✧ Move all: you can move all the messages from SIM card to phone and vice versa and the messages will not be saved in the original carrier.
 - ✧ Use number: to extract the numbers such as the numbers contained in messages, number of sender and the like and carry out the operations of Call, Save, Send Message and so on to the numbers.
 - ✧ Use URL: to extract the website links contained in messages and access them. You can also add this address to bookmark of web service.
- Write message: to create and edit new message in this menu. After editing, you can press function confirmation key to carry out the following operations:
 - ✧ SIM1 done/SIM2 done: after editing, you can select SIM1 or SIM2 to carry out send, save and send, save, send to many and send by group as you need.
 - ✧ Use template: you can select a common phrase in the common phrase menu and insert it in the message.
 - ✧ Insert object: to insert files in folders of picture, my picture, predefined animations, my animations, melody and predefined sound.
 - ✧ Format text: to set the word format with this function including settings of size, style, alignment and paragraph.
 - ✧ Insert PHB number: enter the phonebook and select number from the list then insert it in the message. The record without number will not be showed in list.
 - ✧ Insert PHB name: enter the phonebook and select name from the list then insert it in the message.
 - ✧ Insert bookmark: access the website and select the bookmark from the list then insert it in the message.
 - ✧ Input method: to select the input method.
- Template: to save the common messages and you can edit and delete the common phrases.
- Message settings: to set the relevant parameters of SMS for SIM1 and SIM2.

- ✧ Profile setting: the modes can be set are different to the different SIM card. In each group of mode, you can set name of folder, save or change the message center number which is used for sending message, set the valid period and sending format of the message.
- ✧ Common setting: turn on/off the delivery report and reply path. When the delivery report is on, whether the receiver received or not received your message, the message center will sent a report to you so you can know whether the receiver have received your message.(this needs the supports of network). If the reply path is on, the message the receiver sent will select the message center you used automatically when the receiver use the reply function.
- ✧ Memory status: to see the used memory and total memory of SIM card and phone for SMS. The practical capacity depends on the content of SMS, SIM card and the phone.
- ✧ Preferred storage: to view or change the default archival location for SMS.

6.2 MMS

For MMS is a kind of network service, maybe you need to apply for it to the network operator before sending or receiving MMS. This phone can send and receive MMS. MMS is short for multimedia message containing pictures, sound and text. Your MMS will be sent to MMS center first, and then the MMS center will send the message to the receiver which has MMS function. If the phone of receiver is off or can't receive MMS, the center will save this message for the time being. The term of storage depends on both sender and network operator.

- If the receiver's phone doesn't have MMS function, the MMS center will create a temporary mailbox in special server for saving this MMS for receiver and send a SMS to receiver to read the MMS on the net.
- All the MMS will be saved in internal memory; the SIM card can't save MMS.
- If the memory is full, the phone will give a hint box.
- If the receiver has received and read the MMS, the phone will receive a read report (if the status report is on).

The MMS functions mainly include Write Message, Inbox, Outbox, Drafts, Templates and Settings.

- Write Message: to create, edit and deal with MMS in this menu.
 - ✧ To: press function confirmation key [edit] to enter the number or E-mail of receiver.
 - ✧ Cc: press function confirmation key [edit] to enter the number or E-mail of the other party.
 - ✧ Bcc: press function confirmation key [edit] to enter the number or E-mail of blind copy receiver.
 - ✧ Subject: press function confirmation key [edit] to edit the title of current MMS.
 - ✧ Edit content: press I function confirmation key [edit] to edit the MMS and adding words, pictures, sound, annex and so on is allowed.

After editing, press end key [Done] to deal with the MMS.

- ✧ Send only: to send the MMS to the corresponding receiver.
- ✧ Save and send: the MMS will be sent to the corresponding receiver and saved in Outbox.
- ✧ Save to drafts: to save the MMS to draft box.

- ✧ Send options: to set the relevant options for sending MMS. With this, you can set validity period, turn on/off the delivery report, turn on/off the read report, priority, and delivery time and whether hide number.
- ✧ Exit: to exit the edit interface and the phone will ask you that whether to save the MMS to draft box.

If the receiver was not entered, only saving MMS to draft box or exiting will be finished after press end key [Done].

• Inbox: after receiving the MMS notice, you can do the following operations with Volume control key.

- ✧ Download: to download this notice as MMS.
- ✧ Delete: to delete this notice.
- ✧ Delete all: to delete all the messages.
- ✧ Use details: to extract the phone number, number information and so on contained in the MMS and dial or save them. To extract the E-mail address contained in MMS and to add it to address book.
- ✧ Properties: to view the detail information of the current MMS.

View the received MMS. Select Inbox and enter the list interface. Select the MMS with Volume control key and press options to do the following operations.

- ✧ View: to enter the reading interface.
- ✧ Reply: to reply to the current sender directly by MMS.
- ✧ Reply by SMS: to reply to the current sender directly by SMS.
- ✧ Reply all: to reply to all the persons in phone book.
- ✧ Forward: to send this MMS to others.
- ✧ Delete: to delete the current MMS.
- ✧ Delete all: to delete all the MMS.
- ✧ Save as template: to save the current MMS as template.
- ✧ Properties: to view the detail information of the current MMS.
- ✧ Use details: to extract the phone number, number information and so on contained in the MMS and dial or save them. To extract the E-mail address contained in MMS and to add it to address book.

• Outbox: to view or deal with the MMS saved in Outbox. Select Outbox and enter the list interface. Select the MMS with Volume control key and press options to do the following operations.

- ✧ View: to enter the reading interface.
- ✧ Resend: select it to resend this MMS.
- ✧ Delete: to delete the current MMS.
- ✧ Delete all: to delete all the MMS.
- ✧ Save as template: to save the current MMS as template.
- ✧ Properties: to view the detail information of the current MMS.
- ✧ Use details: to extract the phone number, number information and so on contained in the MMS and dial or save them. To extract the E-mail address contained in MMS and to add it to address book.

- Drafts: view and deal with the MMS saved as drafts. Select it to enter its list interface, and do the following operations with Volume control key.
 - ✧ View: select it to view the current MMS.
 - ✧ Send: select it to send the current MMS.
 - ✧ Edit: select it to enter the editing interface to continue editing.
 - ✧ Delete: to delete the current MMS.
 - ✧ Delete all: to delete all the MMS.
 - ✧ Use details: user can select it to use the numbers or E-mail address.
 - ✧ Properties: to view the detail information of the current MMS.
- Templates: to view and edit the template message and the new message can be generated template. The templates include user-defined and default.
 - ✧ View: to view the template message.
 - ✧ Write message: to make the template message be a new MMS.
 - ✧ Properties: to view the detail information of the current MMS.
 - ✧ Delete: to delete the user-defined MMS template.
 - ✧ Delete all: to delete all the user-defined MMS templates.
- MMS settings: to set relevant parameters of MMS.
 - ✧ Compose: to set creation mode, image resizing, turn On/Off and edit signature settings.
 - ✧ Send: to set validity period, turn On/Off delivery report, turn On/Off read report, priority, delivery time and whether hide number.
 - ✧ Retrieval: to set home network, roaming network, read report state options, turn On/Off delivery report.
 - ✧ Filter: Set whether receive MMS of anonymous sender and ads.
 - ✧ Server profile: to choose different network.
 - ✧ Memory status: to view the rate of used memory, used memory, free memory and the like.

6.3 Chat

This function enables you to chat with others in way of SMS expediently.

Select chatting to enter its list interface. There are two chatting rooms; they are Chat Room1 and Chat Room2. Press function confirmation key to set chatting room or begin to chat.

- ✧ Chat room info: to set your nick name and number of counterpart.
- ✧ Start new: select it to enter editing interface. After the editing, press function confirmation key to send, edit common phrase, insert numbers, and enter names in phonebook and the like. Select send to chat with counterpart in way of SMS.

6.4 Voice Mail Server

This phone supports the voice inbox function, you can set the voice inbox for SIM1 and SIM2 respectively. When you can not answer a call momentarily, the phone can transfer it to your voice inbox and the voice inbox can answer all the calls for you. The left words can be saved in voice

inbox system of service network; the system will remind you that there is new left words or new calls; then you can listen to or reply to all the left words or reply to all the calls any time you like.

- The voice inbox number will be provided by the network operator who serves you and you may need to apply to open this service first. Please turn to the network operator for more information and voice inbox number. The phone will not identify the correctness of the voice inbox number.


- Enter the voice inbox, and setting two voice inbox numbers is allowed. Press function confirmation key to edit and connect to voice.

- ✧ Edit: to add or modify the voice inbox number.

- ✧ Connect to voice: to connect to the current voice inbox number quickly.

6.5 Broadcast message

The cell broadcast refers to the public information sent by network operator. With this service, you can receive information on many kinds of topics from network operator such as life, news, sports, finance and economics and so on and more information was included in each kind. You can read all the information by finishing brief settings.

 **Note:** *the content of cell broadcast information depends on the services provided by the network operator and you may apply to open this service first. Please turn to the local network operator for details.*

- ✧ Receive mode: to turn on/off the cell broadcast.

- ✧ Read message: to read the received cell broadcast.

- ✧ Languages: to select the displaying language of the cell broadcast.

- ✧ Channel setting: to select, add, edit or delete the channels.

- Select: to turn on/off the prepared channels to filter the unneeded cell broadcast.

- Add new: to add the channels and set the names and serial numbers of the channels.

- Edit: to reset the prepared channels.

- Delete: to delete the prepared channels.

7 Call Center

With it you can view the recent call history, and set the correlative item of call.

7.1 Call history

You can view the recent call history of SIM1 and SIM2, and view the call time, call cost at the same time.

7.1.1 Missed Calls

It will show the recent missed calls. Press Volume control key to view the records. Select one to see the details of last missed call including date, time and numbers.

Press function confirmation key to do operations to the current record including delete, save, call, edit, send message and so on.

- ✧ Delete: delete the current call log.
- ✧ Save to phone book: to save the call log to phonebook.
- ✧ Dial: dial this number directly.
- ✧ IP number: When IP dial number has been set and opened, the selected number shall be dialed out by SIM1 or SIM2 with the IP number added before if selected.
- ✧ Edit: edit the number and add it to phonebook.
- ✧ Send SMS: edit a SMS and send to the current number.
- ✧ Send MMS: edit a MMS and send to the current number.

7.1.2 Dialed Calls

It will show the recent outgoing calls. Press Volume control key to view the records. Select one to see the details of last outgoing call including date, time and numbers.

Press function confirmation key to do operations to the current record including delete, save, call, edit, send message and so on.

- ✧ Delete: delete the current call log.
- ✧ Save to phone book: to save the call log to phonebook.
- ✧ Dial: dial this number directly.
- ✧ IP number: When IP dial number has been set and opened, the selected number shall be dialed out by SIM1 or SIM2 with the IP number added before if selected.
- ✧ Edit: edit the number and add it to phonebook.
- ✧ Send SMS: edit a SMS and send to the current number.
- ✧ Send MMS: edit a MMS and send to the current number.

7.1.3 Received Calls

It will show the recent incoming calls. Press Volume control key to view the records. Select one to see the details of last incoming call including date, time and numbers.

Press function confirmation key to do operations to the current record including delete, save, call, edit, send message and so on.

- ✧ Delete: delete the current call log.
- ✧ Save to phone book: to save the call log to phonebook.
- ✧ Dial: dial this number directly.
- ✧ IP number: When IP dial number has been set and opened, the selected number shall be dialed out by SIM1 or SIM2 with the IP number added before if selected.
- ✧ Edit: edit the number and add it to phonebook.
- ✧ Send SMS: edit a SMS and send to the current number.
- ✧ Send MMS: edit a MMS and send to the current number.

7.1.4 Delete Call Log

The user can delete missed calls, dialed calls, received calls or delete all.

7.1.5 Call Time

Not only can the user view the time of last call, but also view the time of incoming calls and outgoing calls. Besides, the user can reset the speaking timer.

7.1.6 Call Cost

The user can control and limit the charges of calls. Not only can the user view the charge of last call, but also view the charges of all calls. Besides, the user can set the charge limit, price or rate and reset the charges.

- ✧ Last call cost: to view the last charge.
- ✧ Total cost: to view the total charge.
- ✧ Reset cost: to delete all the charge records. The reset needs the conformation of PIN2 code. After passing the conformation, you can delete the charge records as you like.
- ✧ Max cost: to view the max charge. The charge limit needs the conformation of PIN2 code. After passing the conformation, you can set the charge limit as you like.
- ✧ Price per unit: to view and set the charge unit. Setting the price and rate also needs the conformation of PIN2 code;



Note: *this function needs the supports of network operator.*

7.1.7 SMS Counter

The user can view the numbers of sent SMS and received SMS.

7.1.8 GPRS Counter

The user can view and count the GPRS flows of last sent, last received, all sent and all received. Besides, the user can reset the GPRS flow records.


7.2 General Call Setting

You can set Call Waiting, Call Divert, Call Barring, Line Switching, Call Time Reminder and Call Time Display and so on.


7.2.1 Call setting

You can set Call ID, Call Waiting, Call Divert, Call Barring, Line Switching and so on for both SIM1 and SIM2.

- ✧ Caller ID: set whether to hide ID when calling out. You can select to hide or send ID. If you select set by network, it shall be determined by the network provider.


 **Attention** *The successful hide is related to the network operator, so please consult the operator first if selecting this item.*

- ✧ Call Waiting: if you have selected to power on this function, you can receive or dial the second call when you are talking with one side, however, the first call shall not be hung up, and you can switch between the two calls. This function shall be turned off if you select close. You can also view the current state of call waiting.

 **Attention** *Call waiting needs the support of network, call barred needs network support and to the application of the service.*

- ✧ Call Divert: the network service only allows you to divert some kind of calling to the preset sound box or another phone number, so as to avoid the missed calls.
 - Divert all voice calls: if you select to activate this function, the all of the calls shall be diverted to the defined number. Select off to cancel the function. You can also view the current state of it.
 - Divert If Unreachable: if you select to activate this function, it shall divert to the defined number if the phone is switched off or out of the service area. Select off to cancel the function. You can also view the current state of it.
 - Divert If No Answer: if you select to activate this function, it shall divert to the defined number if there is no answer. Select off to cancel the function. You can also view the current state of it.
 - Divert If Busy: if you select to activate this function, it shall divert to the defined number if the phone is busy. Select off to cancel the function. You can also view the current state of it.
 - Divert All Data Calls: if you select to activate this function, it shall divert all data calls to the number using PC connection. Select off to cancel the function. You can also view the current state of it.
 - Cancel All Divert: cancel all divert you have set.

- ✧ Call Barring: this item shall prevent your phone from dialing or receiving some kind of calls. As this function needs the support of network service provider, it shall be necessary to get the password for call barring from the network service provider. You will realize the control of the phone through dialing barring and receiving barring.
 - Outgoing calls: select all calls, international calls and international calls except home, and it shall be necessary to input the barring password provided by the supplier if you select on/off. You can also view the current status of outgoing calls.
 - Incoming Calls: select All Calls or When Roaming, and it shall be necessary to input the restrict password provided by the supplier if you select on/off. You can also view the current status of incoming calls.
 - Cancel All: cancel all of the calls barred.
 - Change Barring PW: change the old password.
- ✧ Line Switching: select Line 1 or Line 2;

 **Attention** *You will not be able to dial out the number if you have selected line 2, and the menu shall be different with the sort of SIM card.*

7.2.2 Auto Redial

You can set auto redial when there is no answer. If you select on, the device will auto redial when you dialing and the other side not answer.

7.2.3 Speed Dial

- ✧ Enable Speed Dial: to turn On/Off the speed dial.
- ✧ Set Number: Select set number, select edit(empty) and select numbers from phonebook; select the set number then you can select another numbers from phonebook or delete the set number.

7.2.4 IP Number

The phone is provided with the function of IP number, and you can edit and set three groups of IP numbers at most. If you have selected a certain IP number, select ON from the OPTION to power on the IP number as the current IP calling number, select EDIT to enter IP number and edit it. If you have select IP calling, the mobile phone shall automatically add the activated IP number ahead of the phone number and call out.

7.2.5 More

- ✧ Call Time Display: select to display the current call time or not while calling.
- ✧ Call Time Reminder: select to remind the call time in the process of calling (reminding with “Di”). Select one to enter the setting interface of reminding time; it shall remind you for a long

time id you have edited the time. Select cycle to enter the setting interface of reminding time after clicking OK; it shall remind you when reaching the time you set.


- ✧ Auto Quick End: The user can set the fixed time termination to control the call duration.
 - Set: to turn on/off auto time termination.
 - Time: user can edit the duration time span of auto time termination.

8 Settings

You can customize your phone as you like. The settings include dual SIM settings, pen calibration, security setup and so on.

8.1 Dual SIM Settings

- ✧ Dual SIM open: Select this item, both SIM1 and SIM2 will be used in normal. You can receive the message and call by the two SIM card, and you must select SIM card when you dialing, send message or do operation about SIM card.
- ✧ Only SIM1 open: Select this item, only SIM1 will be used, the SIM2 will not work at all.
- ✧ Only SIM2 open: Select this item, only SIM2 will be used, the SIM1 will not work at all.
- ✧ Flight mode: Select this item, the device will close network service, and the operation of SIM card will be forbidden.

 **Note:** *If only one SIM card is open, and the SIM card haven't be inserted, then the device will display the status of no SIM card.*

8.2 Phone setup

You can set time and date, schedule power On/Off, language, display characteristic, greeting text.

- ✧ Time and date: to set city, date, time and time format.
 - Set home city: enter the city list interface, move the focal point and press OK to finish the operation.
 - Set time/date: enter the edit interface of time/date and enter the numbers through key panel manually; move the focal point to summer time then select on or off.
 - Set format: enter the setting interface to select time format of 12h or 24h and set the date format.
- ✧ Schedule power On/Off: to activate or deactivate the schedule power On/Off. This phone provide 4 times of schedule power On/Off. You can set the status and time of each one.
- ✧ Language: to select the display language of the phone.
- ✧ Preferred Input Methods: After selecting one of input methods, when you enter to edit interface, the default input method is you select.
- ✧ Display characteristic: to set wallpaper, screen saver, power on animation, power off animation and whether show the date and time and show owner number.
 - Wallpaper: enter the wallpaper option interface to select from system or user define; select view to enter the preview interface of the selected wallpaper then press the function confirmation key to save the setting.
 - Screen saver: enter the screen saver interface to turn On/Off and set the waiting time of the screen saver. Besides, you can select from system or user define and press view to enter the preview interface of the selected screen saver then press the function confirmation key to save the setting.

- Power on display: enter the power on animation option interface; you can select from system or user define and press view to enter the preview interface of the selected power on animation then press the function confirmation key to save the setting.
- Power off display: enter the power off animation option interface; you can select from system or user define and press view to enter the preview interface of the selected power off animation then press the function confirmation key to save the setting.
- MainMenu style: to display the themes of this phone.
- Show date and time: to turn On/Off the show date and time displayed on idle screen.
- Show owner number: to turn On/Off the show owner number.
- Clock type: to set the type of clock display in the idle screen, you can select analog clock or digital clock.
- ✧ Greeting text: to turn On/Off and edit the greeting text.
- ✧ Dedicated key: set the shortcut functions of the navigation keys.
- ✧ Auto update of date and time: to turn On/Off the auto update of time.
- ✧ Handwriting: to set the pen speed and pen color.
- ✧ UART setup: to set which of SIM card will be used when backup data, after selecting one of SIM card, you can backup phonebook and message of the SIM when the device synchronize with computer.
- ✧ Color lamp: to turn On/Off the festoon light. When the festoon light is on, the light will flash to the tones and music, for example: incoming tone, message tone, music or video.
- ✧ Twinkling lamp: to select the mode of twinkling lamp. When you select one of the mode, the light will flash to the tones and music, for example: incoming tone, message tone, music or video.
- ✧ Misc setting: to set LCD backlight and backlight duration.

8.3 Network Setup


It enables you to select Network Selection, Preferred Network, to enjoy the network.

- ✧ Network Selection: set to search the network automatically or manually.
- ✧ Preferred Networks: set the preferred network. It is possible to add from the list or add the priority of the user.


8.4 Security Setup

You can use SIM lock, phone lock, auto keypad lock, fixed dial and barred dial to protect the phone privacy in security.

- ✧ SIM1/SIM2 security setup: to set SIM lock, fixed dial and modify PIN or PIN2 of SIM card.
 - SIM Lock: when set the function to ON, you will have to input the PIN number at each time when you power on the phone. Therefore, nobody who does not know the PIN number shall be able to use your phone without your permission. If you want to turn off this function, you must input the PIN number firstly.

 **Hint** *If the PIN number is entered three times in a row, your phone will automatically lock up the PIN number and it is necessary to enter PUK number to unlock (SIM card shall be rejected automatically if the PUK number is entered ten times wrongly!). Please contact the operator of SIM card for if the passwords are not supplied with SIM card.*

- Fixed Dial: if you have set this function (required to enter PIN2 number), you will only call out the numbers stored in the fixed dial list while the common phone book is no long valid when you have input the correct passwords.
- Change Password: set the new password, including PIN1, PIN2. Please keep alive the memory of the new password in case of changing the password.
- ✧ Phone Lock: when set the function to ON, you will have to input the safety code at each time when you turn on the phone.

 **Hint** *The ex-factory original code of the phone is "1122".*

- ✧ Auto Keypad Lock: set the auto keypad lock function of the phone and press OK to enter the setting interface of keypad lock, separately selecting none (the keypad lock is invalid), 5s, 30s, 60s, 5min and within corresponding time. If the phone is in idle state and has no operation, the keypad shall automatically lock to avoid incorrect operation at the time of idle.
- ✧ Change Password: set the new phone lock password. Please keep alive the memory of the new password in case of changing the password.

8.5 Shortcuts

You can store the shortcuts according to your favor, and you can press Function confirmation key to enter the shortcuts list in the idle mode.

Select to enter the shortcuts to display the contents of shortcuts including Pen Calibration, Search Entry, Add New Entry, Caller Group, Owner Number, Memory Status, Preferred Storage, Greeting Text, Volume, Call Divert, Wallpaper and Screen Saver. You can carry out the following operations:

- ✧ Add: add new shortcut to the shortcuts list and select the sequence for added shortcut.
- ✧ Edit: switch to another shortcut in shortcuts list.
- ✧ Delete: delete the current shortcut.
- ✧ Delete All: delete all of the shortcuts, except the preset Pen Calibration.
- ✧ Disable: disable current shortcut.
- ✧ Change Order: change the selecting sequence of this shortcut.

8.6 Pen Calibration

You can set the touch panel to make the touch pen more accurate. Select it and click the center of arrowhead to finish the setting.

8.7 Restore Factory Settings

Select this function to restore the factory settings of the phone. You will have to enter the password

firstly. The default settings that can be restored include caller groups of the phone book, SMS settings, send settings of MMS, the formats of time and date, display setting in idle menu, and the customize of user profiles and so on.

9 MULTIMEDIA

This style of phone is a new mobile communication tool with functions of photographing, listening to music, etc.

9.1 Camera

You can photograph with the built-in pick-up head and adjust the settings. The pictures will be saved in the file system contained in the phone. The pictures are of JPG form. The built-in digital camera will help you record your moving moments.

- ✧ Photographing: At the photographing preview screen, press the function confirmation key to set the phone, and save the setting. After choosing the scenery, press the end key to make sure to go back to scenery screen. When photographing at the scenery screen, the shutter will make a sound. To guarantee the quality of pictures, please keep still the pick-up head for a while. After photographing, the screen will show the static scenery. (The pictures at this moment are of fixed format)
- ✧ Press Volume control key to adjust focus, press function confirmation key and end key to adjust exposure compensation, and press Function confirmation key to take photos.
- ✧ You can get into the following menus when at the photographing and view finding screen.
 - Album: Choose the list screen of getting into the album. The user can check and set your pictures.
 - Camera settings: Choose to get into the camera setting, users can set power on/off or choose the type of shutter voice, such as sound effect 1 level; choose the exposure compensation, such as compensation +1level; choose to avoid coruscating, such as 50Hz, etc; shut or choose to postpone the photographing time, set the photographing time as 5 seconds, 10 seconds, 15 seconds, or shut the photographing time; shut or choose the successively photographing setting, choose to photograph one picture successively, three pictures successively, five pictures successively, or shut photographing pictures successively. Namely to choose the number of photographing successively at key-press photographing.
 - Image settings: Users can set the size and the quality of pictures by choosing to get into the picture settings
 - White balance: Users can choose the methods of auto, daylight, tungsten, cloud, etc, by choosing to get into white balance setting,
 - Scene mode: Users can choose auto or night photographing format.
 - Effect settings: In this screen, the user can choose special effect setting to deal with pictures.
 - Add frame: Choose to get into this screen, the user can cancel or add different frames for pictures.
 - Storage: Save it to memory card.
 - Restore default: Return the camera settings to defaulted setting.

9.2 Image Viewer

Choose to get into album screen, the user can browse and set his pictures in picture list. The user can choose to view, browse style, forward, rename, delete, delete all files, sort, storage, etc.

- ✧ View: Choose to get into picture browsing screen.
- ✧ Browse style: Choose to get into the album screen displaying form, and choose the pictures to display as list style or matrix style.
- ✧ Forward: Choose to set the picture as wallpaper, screen saver, start-up animation, close-down animation, or add the pictures to the phone book in the form of photo stickers, and choose to send pictures in the form of multimedia message.
- ✧ Rename: Change the name of pictures.
- ✧ Delete: Delete the given pictures.
- ✧ Deleting all files: Delete all the pictures saved in the album.
- ✧ Sort: Choose pictures according to the order of name, style, time, size, etc.
- ✧ Storage: Save the pictures to memory card.

9.3 Video Recorder

Shoot and record as you like. The vision enjoys a great function of video record.

- ✧ At the vision screen, press Volume control key to adjust focus, press function confirmation key and right key to adjust exposure compensation, get into "Option" menu and set and save the vision. Press Function confirmation key, and it will shoot. When shooting, press Function confirmation key, and it will pause. Press end key, and it will stop.
- ✧ You can choose to get into the following menu at photographing and view finding screen.
 - Camcorder setting: Choose to get into vision setting, the user can set white balance, for example, auto, etc; Choose exposure compensation, for example, compensation +1 level; Choose to turn on/off night mode; Choose to avoid coruscating, for example, 50Hz, etc.
 - Video setting: Choose to get into film setting, and the user can set the quality of video.
 - Effect setting: Choose to get into this function, the user can choose special effect setting to deal with the pictures.
 - Storage: Save the video to the memory card.
 - Restore default: Renew the vision setting to defaulted setting.

9.4 Video player

The built-in video player in this phone can be used to browse or deal with the video files saved in the video player. The video player supports 3GP, AVI and the AVI pattern file player transformed by the crossover tool. The video files must to save in the "video" folder of file manager.

You can choose to get into the following menu at list screen.

- ✧ Rename: Change the name of video files.
- ✧ Delete: Delete the given video files.
- ✧ Delete all files: Delete all video files.

- ◇ Sort: Order pictures according to the name, style, time, size, etc.
- ◇ Storage: Save the video files to memory card.



Notice: Please see the relevant introduction of the CD data of this phone when download the data and use the crossover tool.

9.5 Audio player

The in-built music player can be used to play music, and the music can be set as ring. When listening to the music, please choose a medium and moderate volume. Sustained over-high volume will do harm to the listener's audition.

The MP3 files must be saved in "My Music" folder; if you want to display lyric, please save the lrc file that the name as the same as mp3 file in "My Music" folder.

- ◇ At the playing screen, function confirmation key [list] is for music list. The user can choose to get into the following menu at list screen, namely, play, detail, add to the ring storeroom, renew the playing list and settings, etc.

- Play: The user can play the given audio files.
- Detail: The user can check the name of the files, sound channel, and timbre, the size of the files and the time of playing music.
- Add to rings : Add the current music to the ring storeroom through shortcut.
- Refresh list: When the list is created automatically,
- Settings: The user can set the player, display, sound effect, etc.

Player settings: Set starting or closing the list of being created automatically, start or close repeated playing, start or close playing following the order of the machine, start or close the background playing.

- List auto gen: When choose to start, the phone will automatically check the music files saved in the music player file, and add it to the defaulted music list. When the choosing function setting is closed, it can add music file from any catalogue through manual operation
- Repeat: It can set the methods of playing repeated music and repeat the current song or the songs in the music list.
- Shuffle: It can play the songs in the music list according to the order of the machine.
- Background play: When choose start, the phone can play music at other operation screen(the operations which are silent or about camera operation are exclusive)

Display setting: Set appearance, energy displaying style, starting or closing the displaying of song lyric in setting.

Sound effects: Choose equalizer effect in setting

Bluetooth setting: The user can turn on/off the output of Bluetooth dimensional sound and the Bluetooth dimensional sound headphones

If the list created automatically is turned down, the user can choose to add delete or delete all files.

- Add: Get into file manager and choose music file.

- Delete: Delete the current music file in the list.
- Delete all files: Delete all music files in the list.

9.6 Sound Recorder

The users can record and listen to their own record through this function.

- ✧ Choose to get into the record list screen, if there is no record file, it will display an empty binder.
The user can choose the options and get into the following menus.
 - Record: When choose the function of recording, it will start to record. The function confirmation key is for pausing, press it again and the record will continue. The end key is for stopping and getting into editing the name of the record. After editing, choose saving, and the system will save the record.
 - Settings: After choosing, save the record in the memory card, and set the file pattern and the sound quality of the record.
- ✧ Choose to get into the recording list screen, move the direction key to choose the recording file.
The user can choose the options and get into the following menus.
 - Record: Choose recording, it will start to record.
 - Play: After choosing, it will start to play focusing recording file.
 - Append: Continue to record this file.
 - Rename: Change the name of the current recording file.
 - Delete: Delete the current recording file.
 - Delete all: Delete all recording files in the list.
 - Settings: After choosing, save the record in the memory card, and set the file pattern and the sound quality of the record.
 - Forward: The user can send the current recording file to the list of incoming rings of the Audio profiles, and send the record as multimedia message.

10 FILE MANAGER

The phone can manage the files intelligently, which is convenient for the user to check and manage. When insert the memory card, the file manager can be used to manage all kinds of files, such as photos, pictures, e-book, records, and video, etc. And you can operate to check, edit, send, delete, change the name, etc.

- ✧ At file manager list screen, you can check the internal storage, used space, percentage of the used space, etc.
- ✧ You can choose the options and get into the following operations at the main menu screen of file manager.
 - Open: Choose “open”, you can get into the next lower level folder list screen.
 - Create folder: Choose to get into the folder editing screen, when finish inputting, you can establish a new folder at the next lower level of the current catalog.
 - Format: Formatting will remind you whether to format. “Confirm” is to clear up all data. (folders and files)
 - Remove: Choose the file information which is going to delete. When the list screen focus of file manager is on the memory card, choose “delete” to delete folder.
- ✧ When the focus is on the folder, you can choose the options and get into the following operations:
 - Open: Choose “open” and get into the next lower level screen of focal folder.
 - Create folder: Choose to get into the folder editing screen, when finish inputting, you can establish a new folder at the next lower level of the current folder
 - Rename: You can change the name of the folder to satisfy yourself.
 - Delete: Choose the file information which is gong to delete.
 - Sort: Choose to order according to the names, types, time, size, etc.
- ✧ When the focus is on the file, you can choose the options and get into the following operations:
 - Play/Read/View: When the focus is on the audio file or video file, this item is for playing. And play the file immediately after choosing. When the focus is on the text file, this item is for reading. You can read the e-book after choosing. When the focus is on picture file, this item is for view. You can open the pictures and preview them after choosing.
 - Forward: You can send the audio file to the Audio profiles, and send the audio file and picture file as multimedia message. You can also set the picture file as wallpaper, screen saver and start-up animation, or add them to the head stick of the phone book. You can also send the text and video file as multimedia message. The video file can be set as screen saver and start-up animation, or added to the incoming video recorded in the phone book.
 - Detail: Check the date, size of the file.
 - Rename: Rename the file.
 - Copy: Duplicate the file and choose the folder for the file. After choosing, you can duplicate the selected file to the appointed folder.
 - Move: Move the selected file to another folder, and the former file doesn't exist anymore.

- Delete: Delete the selected file
- Sort: Choose to order according to the name, type, time, size, etc.

11 FUN & GAMES

This phone has provided you with funny games.

11.1 Games

Choose games, and get into the game menu by pressing function confirmation key.

- ◇ Mah jong: Get into this menu by pressing function confirmation key
 - Start game: Press function confirmation key to make sure to start a new game.
The operating instructions are as follows:
Choose two same mah-jongs, and if they can connect with each other within two turnings, they can be counteracted.
 - Resume : During the game, the end key is for exiting. The user can choose “resume” to continue the unfinished game.
 - Game Level: Set the degree of difficulty. The more difficult, the quicker.
 - Best grades: It displays the highest scores of every level of every game. Choose “reset” to clear up all the records of the highest scores.
 - Game help: It displays the game instruction, which will help you get more familiar with the game.
- ◇ Puzzle: Press the function confirmation key to get into this menu.
 - Start game: Press the function confirmation key to make sure to start the new game.
The operating instructions are as follows:
➤ Resume: During the game, the end key is for exiting. The user can choose “resume” to continue the unfinished game.
 - Game level: Set the degree of difficulty. The more difficult, the more pieces of segments.
 - Best grades: It displays the highest scores of every level of every game. Choose “reset” to clear up all the records of highest scores.
 - Game help: It displays the game instruction, which will help you get more familiar with the game.
- ◇ Magicsushi: Press the function confirmation key to get into this menu.
 - Start game: Press the function confirmation key to make sure to start a new game.
The operating instructions are as follows:
Make sure three or more sushi with the same pattern align together vertically or horizontally by swapping one sushi with any neighboring one. During playing, click star block, randomly remove sushi with a certain pattern, click cross block, remove the whole row and whole column it resides, click ball block, remove 8 sushi surrounding it.
 - Resume : During the game, the end key is for exiting. The user can choose “resume” to continue the unfinished game.
 - Best grades: It displays the highest scores of every level of every game. Choose “reset” to clear up all the records of highest scores.
 - Game help: It displays the game instruction, which will help you get more familiar with the game.

- ✧ Vsmj: Press the function confirmation key to get into this menu.
 - Start game: Press the function confirmation key to make sure to start a new game.
The operating instructions are as follows:
Use the direction key to select mahjong, press Function confirmation key to send it out. Make 5 sets of links or triples and a pair to win the game.
 - Resume: During the game, the end key is for exiting. The user can choose “resume” to continue the unfinished game.
 - Game Level: Set the degree of difficulty. The more difficult, the quicker.
 - Best grades: It displays the highest scores of every level of every game. Choose “reset” to clear up all the records of the highest scores.
 - Game help: It displays the game instructions, which will help you to get more familiar with the game.
- ✧ Game setting: The user can set whether to open or close the background sound effect, game sound effect or vibrator to add pleasure.

12 USER PROFILES

There are several modes in the phone, you can adjust and set the rings according to different occasions and surroundings. First you can make a personal setting according as you like, then you can start the corresponding mode.

The supplied modes are: general, meeting, outdoor, indoor, Bluetooth and so on.

If you want to select the general mode, meeting mode, outdoor mode or indoor mode, you can take the following operations.

- ✧ Activate: open up the selected mode.
- ✧ Customize: users can take the personal settings according to different surroundings. Select the settings that need to be changed, it includes: tone setup, volume, ring type, extra tone and answer mode.
 - Tone setup: you can set the ring of incoming calls, opening ring, ending ring and message ring.
 - Incoming call: you can choose any rings in the internal rings and file management as your ring of incoming calls. You can set incoming call for SIM1 and SIM2.
 - Power on: you can set your opening ring as mute mode or choose one from the internal rings.
 - Power off: you can set your ending ring as mute mode or choose one from the internal rings.
 - Message tone: you can set your message ring into mute mode or choose one from the internal rings. You can set message tone for SIM1 and SIM2.
 - Keypad tone: you can choose mute or tones as your key-press ring.
 - Volume: you can set the volume of the ring and key-press ring by pressing the Volume control key
 - Alert type: you can choose the ringing type, they are ring, vibration only, vibra and ring, vibra then ring. You can press the function confirmation key after you select the proper type.
 - Ring type: you can choose the types of tones. Repeat, single or ascending. You can press the function confirmation key after you choose the proper type.
 - Extra tones: you can choose to open up or close the warning tones under certain conditions. If you select the warning, the warning tone rings for the operation warnings. If you select the error, the warning tone rings for the operation errors. If you choose the camp on, the warning tone rings for the successful net searching. If you choose the connect, the warning tone rings after it gets through.
 - Answer mode: if you select this mode, you can answer calls by pressing any key.

After you insert the earphone into the phone, it switches into the headset mode automatically. If the Bluetooth earphone has been connected successfully and the sound path of the facility has been set as the Bluetooth earphone mode, it switches into the Bluetooth mode automatically. You can take the personal setting to the headset mode and Bluetooth mode. The setting way is the same to that of the common mode.

13 ORGANIZER

You can set your alarm clock, make brief recording and check the calendar and universal time in the tool box.

13.1 Calendar

You can check the date at anytime. It display the current time of the system when you enter into the calendar.

- ✧ View tasks: you can choose to enter into the calendar of the date where the focus point is.
 - If there is no record in the date where the focus point is, you can press the function confirmation key to add the new recording.
 - Users can choose the mode of meeting, course, date, call, anniversary and so on. If you have decided the mode, you can edit the starting time and ending time, open or close the alarm clock, set the response mode as everyday response or every week response, and choose the remarks, address and PRI.
 - If there is calendar recording at the date where the focus point is, you can operate in the following ways:
 - View: check the current selected records.
 - Add: you can add new calendar records, for example meeting, course, date, call, anniversary and so on. Edit the date, time, remarks, alarm clock and other options after you select the records.
 - Edit task: edit and alter the selected date, time, remarks, alarm clock and other contents.
 - Delete task: delete the current routings.
 - Delete all: delete all the routings.
 - Send vCalendar: you can send the current routings via SMS or MMS or save the routings in the file management.
- ✧ Add task: you can add new records. If you have selected the mode as conference, course, date, calls, or commemoration and so on, you can edit the starting time and ending time, open or close the alarm clock, set the response mode as everyday response or every week response, and choose the remarks, address and PRI.
- ✧ Jump to date: press [OK] after you input the appointed date, it will leap to the calendar interface at this date.
- ✧ Go to Weekly view / go to monthly view: You can choose the regulation of the calendar interface as daily or weekly display.
- ✧ Print: connect the printer by Bluetooth, then you can print the current calendar page.

13.2 To Do List

You can save the important things and set different warning time.

If you have entered into the display of all the routings, you can operate in the following ways:

- ✧ View: check the current selected records.

- ✧ Add: you can add new calendar records, for example meeting, course, date, call, anniversary and so on. Edit the date, time, remarks, alarm clock and other options after you select the records.
- ✧ Edit task: edit and alter the selected date, time, remarks, alarm clock and other contents.
- ✧ Delete task: delete the current routings.
- ✧ Delete all: delete all the routings.
- ✧ Send vCalendar: you can send the current routings via SMS or MMS or save the routings in the file management.

13.3 Alarm

The phone will warn you by tones or vibration when the time you set is up. You can set at most 5 alarm clocks at the same time.

In any alarm clock, press the function confirmation key and then press [Edit] to enter into the menu interface.

- ✧ The alarm time: you can input the time on the keyboard.
- ✧ The alarming period: you can set the period of alarming, there are three optional modes: daily alarm, namely it will alarm once everyday from Monday to Sunday. Use-defined alarming, namely you can choose some of the days as the alarming days. One-time alarming, namely it will alarm once at the time you set.
- ✧ The setting of rings: you can choose tones or broadcast voices as your ring, or you can select the tone type or the broadcasting frequency.
- ✧ Snooze: you can set the permitted delaying time.
- ✧ Alert type: you can set the alert types, there are tones, vibration or vibration and tones.



Notice: *you can set one or some of the alarm clock. They still work when the phone is turned off.*

13.4 World clock

Press the function confirmation key to enter into the option menu, you can start or end the summer time

13.5 Calculator

Your phone is provided with simple arithmetic operation function.

- ✧ M+: add the imputed numerical value to the value stored in temporary storage and store the result in temporary storage, and the valued displayed on the display is the value stored in temporary storage;
- ✧ M-: subtract the imputed numerical value from the value stored in temporary storage and store the result in temporary storage;
- ✧ MR: it is possible to call the value stored in temporary storage and display it;
- ✧ MC: empty the value in temporary storage.



Hint The calculator supports the input of negative numbers. If you want to input the negative number as the operands, it shall only be necessary to input the “-” before the number.

13.6 Currency Converter

Your phone is provided with simple currency converter function.

13.7 Stopwatch

The user can choose the ordinary stopwatch or the multidimensional stopwatch according to different needs.

Typical stopwatch: The user can choose to time respectively or to time by circle to calculate the different periods of time.

- ◇ Split timing: Choose to get into the initial Time Respectively screen. The initial Time Respectively screen displays “00: 00: 00: 00”, which means “hour: minute: second: millisecond”.
 - At the initial Time Respectively screen, choose function confirmation key to start. Press end key once [Split] it will note the time from the moment the stopwatch begins to the first period of this operation. Press end key again [Split], all the records will be accumulated from the first moment to time and displayed in a list.
 - During the process of timing, choose function confirmation key [stop] to pause timing, choose function confirmation key [Resume] to accumulate. At this time, choose end key [Back], the system will remind you whether to save the record. If save, edit the name of the record.
- ◇ Lap timing: Choose to get into the initial Time by Circle screen. The initial screen displays “00: 00: 00: 00”, which means “hour: minute: second: millisecond”.
 - At the initial time by Circle screen, choose function confirmation key to start. Press end key once [Lap], it will note the time from the moment the stopwatch begins to the first period of this operation. Press end key again [Lap], all the records will be retimed from the last time respectively. The next time to time is at the moment when the stopwatch restarts and it will be displayed in a list.
 - During the process of timing by the stopwatch, choose function confirmation key [Stop] to pause timing, choose function confirmation key again [Resume] to accumulate. At this time, choose end key [Back], the system will remind you whether to save the record. If save, edit the name of the record.
- ◇ View record: You can not only check the record split timing and lap timing, but also delete all the records.

nWay stopwatch: The user can record different time at the same time.

- ◇ nWay stopwatch: Choose to get into the initial multidimensional stopwatch screen. The initial screen displays “00: 00: 00: 00”, which means “hour: minute: second: millisecond”.
- ◇ Choose a kind of stopwatch to time, others will be paused, if continue to time by another kind of stopwatch, the former kind will be paused.

13.8 E-Book Reader

You can read the EBooks downloaded from other places in your phone.

Select E-Book Reader to enter the interface of EBook list, move the focus to the EBook you want to read. Select the function confirmation key to fulfill the following operations.

- ✧ Read: enter the reading interface if selected and you can use the shortcuts enabling you the convenient reading mode.
- ✧ Press the function confirmation key to carry out the following operations during reading.
 - Find: it shall hint you Case Sensitive/Case Insensitive if selected. Input the passwords and search in the contents of the current E-Book of selected.
 - Jump To: jump to the page convenient to your reading if selected.
 - Go To Bookmark: select to enter the interface of Bookmark Name List.
 - Add Bookmark: you can set bookmarks to facilitate your reading. Select this item to enter the editing interface of Bookmark and then press Done to store it.
 - Delete Bookmark: you can delete the set bookmark.
 - Book Info: select to view the details of the E-Book, including Title, Size and Format and the like.
 - Settings: select this to enter the setting interface of E-Book and just select done after setting.
 - Font Style: you can set the font style of the contents of the E-Book, such as bold and italic and the like.
 - Font Size: you can set the font size of the contents of the E-Book.
 - Scroll By: you can set to scroll the contents of the E-Book in form of page or line.
 - Auto Scroll: you can turn on/off the auto scroll.
 - Scroll Speed: you can set the auto scroll speed according to your custom.
 - Full Screen: you can set whether to display the contents of the E-Book in full screen or not.
 - Encoding: you can set the encoding format of the contents of the E-Book.
 - Apply Global Settings: it shall hint to restore default settings or not if selected. If yes, the default settings of the E-Book shall be restored immediately.
 - Help: select to provide you with the convenient instructions.
 - Close: select to close the E-Book and back to bookshelf.
- ✧ CleanUp Bookshelf: select to rearrange the E-Book.
- ✧ Global Settings: select to enter the setting interface of E-Book and select Done to finish the setting.
- ✧ Book Info: select to view the details of the E-Book, including Title, Size and Format and the like.
- ✧ Delete: delete this E-Book.
- ✧ Delete All Files: delete all of the E-Books.
- ✧ Sort: select to sort the E-Books according to the name, type, time and size and the like.
- ✧ Apply Global Settings: it shall hint to restore default settings or not if selected. If yes, the default settings of the E-Book shall be restored immediately.

- ◇ Help: select to provide you with the convenient instructions.

13.9 Bluetooth

Your phone is equipped with Bluetooth technology, enabling you to connect the phone wirelessly to other Bluetooth devices and exchange data with them, talk hands-free. It is possible to realize the free wireless interconnection among all of the Bluetooth compatible devices within the distance of 10m through Bluetooth technology, and to transmit the information including images, video segments and music and the like.



Hint 1. *Bluetooth wireless technology may be limited in some places. Please consult the local competent authorities or service provider.*

2. *Using the function of supporting Bluetooth wireless technology shall increase the power consumption when it is running at background, and thus the service life of the battery shall be shortened.*

If you have selected Bluetooth, the following function menus shall be used:

- ◇ Power: it is possible to switch the open/off state of Bluetooth devices through this function. If it is necessary to use Bluetooth, make sure to set the Bluetooth to **open**.
- ◇ Inquiry audio device: turn on Bluetooth state and automatically search the hand-free device within effective distance. Enter the interface of searching Bluetooth hand-free device, and the connecting function shall be used when the hand-free device has been found.
- ◇ Remote control: if the PC is equipped with Bluetooth device, it shall be possible to connect the phone Bluetooth from PC automatically, and set the phone Bluetooth to visit the services of PC. In case of successfully setting, the types of remote control shall be displayed in the phone, including desktop, media player and presenter;
 - Desktop: it is used to control the desktop of PC through the phone;
 - Media player: it is used to control the multimedia player of PC through the phone;
 - Presenter: it is used to control the demonstration of film slide of PC through the phone;
- ◇ My device: this function shall list the Bluetooth devices which have communicated with your phone. Following operations shall be done to the listed Bluetooth devices:
 - Connect: connect to this device and select the service to realize different connecting purposes when connecting.
 - Rename: you can change the name of the device through this function and it shall be convenient for you to memory and identify.
 - Delete: delete this device from the devices list.
 - Delete all: delete all of the devices from devices list, that is to empty the list.
 - Service list: list all of the Bluetooth services provided by the equipment, and it shall be possible to acquire again by clicking renewal soft key.
 - Search new device: if there are some new devices entering the environment of your phone, you can search thus devices by using this function. If you have searched out the new device, the other side shall be recorded in device list after matching up. It may be necessary to enter the identifying code of the other side while matching up, and then the

service list provided by the other side shall be updated when the identifying code has been passed.

- ✧ Active devices: to view the Bluetooth devices online. If you have connected other Bluetooth devices, such as Bluetooth earphone, the device shall appear in the list of online devices and it shall be able to be switched off.
- ✧ Setting: you can modify the Bluetooth settings of the phone in this function.
 - Visibility: if it is available to select others to search, check whether your phone can be searched out or not.
 - Change device name: you can modify the name of Bluetooth device in your phone if selected.
 - Authentication: select to enter the identifying code or not when matching up the Bluetooth devices and connecting.
 - Audio path: you can select to talk with the phone or Bluetooth earphone when the Bluetooth earphone has been connected.
 - FTP setting: to modify the settings when using Bluetooth to transmit files.
 - ◆ Shared folder: it is the shared directory when you transmit files with Bluetooth. You can define a directory on the memory card as a shared directory. When you transmit files through Bluetooth, the received files shall be stored under this directory, and the files to be shared with others shall also be under this directory.
 - ◆ Access right: the shared directory is able to in file or not. When you share the files with others, you can select **read permissible**; if you want to acquire files form others, it shall be necessary to select free acquisition.
 - Remote SIM mode: this function shall permit other devices to use SIM card to connect with the network.
- ✧ About: users can view the details of Bluetooth, including the Bluetooth name, Bluetooth device address and services.

Send data through Bluetooth connection:

You can turn on only one Bluetooth connection at a time.

- Open the application program storing the contents required to be sent. For example, it is necessary to open the multimedia when sending images to another compatible device.
- Select the content to be sent: such as an image, then select Option- Send – To Bluetooth.

The phone begins to search for other devices with in effective distance, and the other devices supporting Bluetooth wireless technology within the effective area shall be shown on the screen. Select the device to be connected. If the transmission of data of the other device shall only be available after matched up, the phone shall send out the hint and ask you to input the patching code. You can send the data through Bluetooth after the completion of matching and connecting.

Receive data through Bluetooth connection:

When you receive data through Bluetooth connection, the phone shall hint and ask whether to receive or not. In case of receiving data, it shall begin to receive the Bluetooth input data and store it

under separate directory; in case of not receiving, it shall reject to receive the data transmitted by Bluetooth.

14 SERVICE

This phone supplies you several WAP services, for example, banking business, news, weather reports, flight time table and so on. You can visit the website the mobile net supports and get abundant net information resource.

14.1 WAP

You can visit many kinds of WAP (Wireless Application Protocol) services, which are designed especially WAP service.

Please consult your network operator or the service provider when you have some problems about WAP service. The service provider will provide you with the instruction about how to use the service.

Choose WAP and get into the menu screen.

- ✧ Homepage: Choose “confirm” and directly get into the set first page of website and visit it.
- ✧ Bookmarks: Choose to confirm the set bookmarker list, and you can get into the network bookmarker list set by you to surf directly. In order to transfer or open the
 - Goto: Choose “OK” and directly get into the websites in which the bookmarker is in and visit it.
 - Edit: After choosing, get into editing screen and continue to change the address and title of the bookmarker, choose “Done” and it will be done.
 - Delete: Delete the current bookmarker.
 - Delete all: Delete all bookmarkers.
 - Add bookmark: After choosing, get into editing screen and input the address and title of your expected bookmarker, choose “Done” and it will be done.
 - Set as the homepage: After choosing, set this bookmarker as the first page of the website. When you choose the first page, you will directly get into the websites in which the bookmarker is in and visit it.
- ✧ Recent pages: The web pages which have been logged in recently through phones will be saved in the menu. And the user can choose the record in this menu directly to surf.
- ✧ Enter address: After choosing, get into editing screen and input the web site which you are going to log in, then the system will start to connect this web page. After editing the website, you can get into the following operations.
 - Goto: Choose “Ok” and directly get into the websites and visit it.
 - Edit: After choosing, get into editing screen and continue to change the web site, choose “Ok” and it will be done.
 - Add to bookmarks: After choosing, get into editing screen and input the title which is corresponding to the web site and it will be done.
 - Delete: Delete the current web site.
 - Delete all: Delete all web sites.

- ✧ Service inbox: This function means the service provider sends the content of WAP to the phone, and you needn't do anything. For example, you can get the latest news or new WAP settings from the service provider.
- ✧ Settings: You can choose to set the "edit profile", "browser options", "service messages", "clear cache", "clear cookies". Different network operators provide different parameters, and they can also change the WAP parameters. The defaulted parameter is provided by the network operator and it may be preset in your phone.
 - Edit profile: Before connecting network, please set WAP. After the right setting according to the local network, then the user can surf on the net. After choosing setting, you can get into the following operations.
 - Activate profile: After choosing, the system will start network connection.
 - Edit profile: After choosing, the user can change every setting, such as the change of the name, the input of the first page website, the selection of the shape of connection, the input of the user's account numbers, and the input of the user's password.
 - Browser options: Set the holding time needed when connecting network and turn on/off displaying a picture.
 - Timeout: The user can set the holding time needed when connecting network
 - Show images: The user can set whether to display a picture when browsing the network.
 - Address as: The user can set the browse display as a title or the website.
 - Image selection: The user can set whether he can choose a picture or not when browsing the network.
 - service messages: Choose to turn on/off to receive network service information
 - Clear cache: The user can clear buffer memory.
 - Clear cookies: The user can clear personal information.

14.2 Data Account

The user can check the relevant data about the account. After choosing, get into GSM data or GPRS.

- ✧ GSM data: After choosing, get into GSM data list screen, and choose anyone to edit. The user can change the name, data number, the input of the user's account numbers, the input of the user's password, and the selection of the shape of line.
- ✧ GPRS: After choosing, get into GPRS list screen, and choose anyone to edit. The user can change the name, connection point, the input of the user's account numbers, the input of the user's password, authentication pattern.

15 TRANSMISSION

When the phone is in off state, connect the phone to PC with the data line in accessories, and then the phone shall be identified as a moveable hard disk. You can visit this moveable hard disk and copy the data from PC to the corresponding directory of the moveable hard disk, that is to say, download the data form PC to the phone.

If the formatting operation is done to the phone, the directories will be deleted, at this moment, you can select the functions to enter from the menu, and the system will automatically set up the corresponding directories.

When the phone is in on state, you can also connect the phone to PC with data line, and then the phone shall show a USB setting menu, including three options: mass storage, webcam and com port.

- ✧ Mass storage: select this item, the phone shall enter USB preferred storage mode, and it shall be identified as a moveable hard disk by PC. The operations of this moveable hard disk are as before. In this mode, some of the functions shall not be used until disconnect the data line, such as camera and the like.
- ✧ Webcam: if you have selected this item, the phone shall be connected to the PC as a USB camera. You can carry out the network video chatting with it just like use a common image pickup device.
- ✧ Com port: this is the data interface of USB stimulating serial port, which shall be use for visiting SIM card and the reserved memory in the phone. You can reserve the phone book and SMS to your computer after installing the corresponding drivers and synchronous software. As this operation is a high-class function, the common users are not recommended to use it.

16 FITTINGS

You can select any of these listed fittings to work in your wireless phone. For other fittings, please check with your dealer.

✧ Accessional batteries

You can select other batteries with diverse capability supplied by our corporation.

✧ Travel chargers

These are exceeding light-duty, applied and fast chargers. It can charge quickly for your wireless phone. Plug the charger to the electrical plug, and plug the other end to the accessory surface in the bottom of wireless phone.

You can examine the state of charge from the screen of wireless phone, It can't auto switch on when the state is off. During charge the battery, you can press the power key to switch on your wireless phone.

✧ Earphone

The portable and cabinet earphone shall provide you with excellent tone and convenient operation mode.

Precautions concerning the using of fittings are as follows:

- ✧ Please the fittings out of the touch of children;
- ✧ Please pull out the plug rather than the power line when switching off the power supply of any fittings;
- ✧ Regularly check that all of the phone facilities in auto are installed and operated correctly.

Warning

If the user fails to observe the above mentioned suggestions or user the phone in a wrong way, the manufacture shall not be responsible for the aftereffects resulting from it.

Note

In case of updating the version, no additional notice will be given. The corporation owns the document's ultimate authority for the interpretation.